



Training Solutions, Delivered!

PREVENTING FIRES DURING HOT WORK OPERATIONS *(Concise)*

**Leader's Guide, Fact Sheet
& Quiz**

Item Number: 4603

© AP Safety Training

This easy-to-use Leader's Guide is provided to assist in conducting a successful presentation.

PREPARING FOR THE MEETING

Here are a few suggestions for using this program:

- a) Review the contents of the Fact Sheet that immediately follows this page to familiarize yourself with the program topic and the training points discussed in the program. The Fact Sheet also includes a list of Program Objectives that details the information that participants should learn from watching the program.
- b) If required by your organization, make an attendance record to be signed by each participant to document the training to be conducted.
- c) Prepare the area and equipment to be used for the training. Make sure the watching environment is comfortable and free from outside distractions. Also, ensure that participants can see and hear the TV screen or computer monitor without obstructions.
- d) Make copies of the Review Quiz included at the end of this Leader's Guide to be completed by participants at the conclusion of the presentation. Be aware that the page containing the answers to the quiz comes before the quiz itself, which is on the final page.

CONDUCTING THE PRESENTATION

- a) Begin the meeting by welcoming the participants. Introduce yourself and give each person an opportunity to become acquainted if there are new people joining the training session.
- b) Introduce the program by its title and explain to participants what they are expected to learn as stated in the Program Objectives of the Fact Sheet.
- c) Play the program without interruption. Upon completion, lead discussions about your organization's specific policies regarding the subject matter. Make sure to note any unique hazards associated with the program's topic that participants may encounter while performing their job duties at your facility.
- d) Hand out copies of the review quiz to all of the participants and make sure each one completes it before concluding the training session.

4603 PREVENTING FIRES DURING HOT WORK OPERATIONS (*Concise*) FACT SHEET

LENGTH: 9 MINUTES

PRODUCTION YEAR: 2014

PROGRAM SYNOPSIS:

Welding, grinding, cutting, open flame and other spark producing tools and operations are all capable of starting dangerous fires in our workplaces. Collectively known as hot work, such processes require specific permits and procedures be followed to prevent the ignition of vapors, liquids and solids that may be in or near the work area. Careless hot work operations can quickly lead to fires, extensive property damage, severe injuries or death. This program discusses the safe work practices that should be taken to prevent such incidents and reviews the responsibilities of those workers involved in hot work tasks.

Topics include the hot work safety program, designated hot work areas, safety precautions to be taken prior to a hot work operation, the circumstances that require a fire watch, communication with outside contractors and responsibilities of the permit authorizing individual, the fire watch and the hot work operator.

PROGRAM OBJECTIVES:

After watching the program, the participant will be able to explain the following:

- Topics included in a typical hot work safety program;
- Precautions that must be taken before a hot work operation begins;
- The duties of the permit authorizing individual;
- Responsibilities of the fire watch and the hot work operator;
- The safeguards that should be discussed with outside contractors.

PROGRAM OUTLINE

THE HOT WORK SAFETY PROGRAM

- Preventing injury and property damage during hot work operations is the purpose of your facility's hot work safety program.
- Hot work can be defined as "work that involves open flame, sparks and heat-producing activities." These types of activities are commonly associated with welding, cutting, grinding and brazing operations.

DESIGNATED HOT WORK AREAS

- In most circumstances, hot work involves some type of maintenance work or fabrication. Some work areas have been designed as a safe and permanent location for hot work to be performed.
- These "designated areas" for hot work should be free of combustible materials, have a non-combustible working surface, be equipped with appropriate mechanical ventilation, have a fire extinguisher and be suitably segregated from adjacent work areas.
- When possible, objects requiring hot work should be moved into a designated hot work area.
- When hot work is performed in these types of approved and designated areas a hot work permit is not required; however, there are often times when a piece of equipment is too large to move into a designated area or the work to be done involve pipes and other objects, which must be left in place.

HOT WORK PERMITS

- When this is the case and hot work must be performed in a "non-designated" area, a hot work permit will be required.
- The hot work permit will outline the special precautions which must be taken to ensure everyone's safety during hot work operations.
- The person who issues the hot work permit, called the permit authorizing individual or "PAI" by some organizations, must verify all precautionary measures have been taken before signing the permit and allowing work to begin.

SAFETY PRECAUTIONS TO TAKE PRIOR TO A HOT WORK OPERATION

- The equipment used for performing the hot work operation or task should be inspected to ensure it is in good operating condition.

- Before beginning work, employees involved in the hot work must select the appropriate personal protective equipment and clothing.
- Wood shavings, paper clippings and other ignitable debris should be swept clean for a radius of at least 35 feet from the worksite.
- If the floor is composed of material that could ignite, it should be wet down, covered in wet sand or covered in approved welding blankets or pads.
- All ignitable materials should be removed to a location at least 35 feet from any possible ignition source.
- If materials or objects that could ignite cannot be moved, they should be covered by an approved welding curtain, blanket or pad or a welding screen should be placed in front of them to prevent contact with sparks, slag or anything else that could cause them to ignite.
- If hot work is done on one side of a wall, partition, ceiling or roof, combustibles on the other side must also be removed or a fire watch must be stationed if relocating the combustibles is impractical.
- Openings or cracks in walls or floors within 35 feet must also be covered or sealed with an approved material to prevent the passage of sparks.
- Ducts and moving conveyors that could carry sparks to ignitable materials in other locations must be shielded or shut down, or both.
- Fully charged and operable fire extinguishers, appropriate for the class of any potential fire, must be readily available in the work area.
- Precautions must also be taken to prevent the accidental operation of sprinkler systems and other automatic fire suppression methods while the hot work is being performed.

DUTIES OF THE PERMIT AUTHORIZING INDIVIDUAL (PAI) & THE HOT WORK OPERATOR

- In situations where sparks, slag, or other ignition sources may travel farther than 35 feet, the permit authorizing individual may extend the distance of the combustible-free zone.
- Based on local conditions, the permit authorizing individual will determine the length of time for which the permit is valid.
- The operator must constantly be aware of conditions in the immediate work area and within the fire-safe radius established by the permit. The area should be kept in good order, free of ignitable materials and tripping hazards.
- Keeping an orderly work area free of ignitable materials is a safe work practice that also applies to designated hot work areas.
- The PAI must inspect the hot work area at least once per day while the permit is in effect to make sure it is safe from fire.
- Upon notice that the work has been completed, the PAI will verify that the area is safe and then close out the permit in accordance with your organization's policies.
- Any fire suppression systems that were shut down during the work must be reactivated.
- The hot work permit is then stored for a period of time specified in the company's written hot work safety program.

FIRE WATCHES

- Many hot work operations require a fire watch. A fire watch is a properly trained and authorized person responsible for keeping the hot work operation in a fire-safe condition as well as watching for fires after the work is completed.
- The fire watch must be performed by someone who understands the hazards of the hot work being performed and the limitations placed on the hot work operation by the permit and the permit authorizing individual.
- The fire watch has the responsibility to make certain the hot work area is maintained in a fire-safe condition throughout the performance of the hot work and has the authority to stop the hot work if unsafe conditions are observed.
- The fire watch should be properly trained in the use of fire extinguishers and have an appropriate extinguisher readily available during a hot work operation.
- The fire watch should only attempt to extinguish a fire which is obviously within the capacity of the extinguishing equipment available.
- The fire watch must be stationed in the area for at least one half hour after completion of the hot work in order to detect and extinguish smoldering fires.

SUMMARY

- Performing hot work is an essential part of our production and maintenance operations.
- Hot work has the potential to be hazardous, but its hazards can be controlled by following safe work practices:
 - 1) Working in well-kept designated areas whenever possible;
 - 2) Removing or controlling combustibles when working in non-designated areas;
 - 3) Establishing a proper fire watch when required;
 - 4) Following the requirements outlined in the hot work permit.

PREVENTING FIRES DURING HOT WORK OPERATIONS (*Concise*)

ANSWERS TO THE REVIEW QUIZ

1. a

2. d

3. a

4. a

5. c

6. b

7. a

8. d

9. b

PREVENTING FIRES DURING HOT WORK OPERATIONS (Concise)
REVIEW QUIZ

The following questions are provided to determine how well you understand the information presented in this program.

Name _____ Date _____

1. Some common examples of hot work include welding, cutting, grinding and brazing.
 - a. True
 - b. False

2. Designated work areas should be _____.
 - a. Free of combustibles
 - b. Have a fire extinguisher
 - c. Separated from adjacent work areas
 - d. All of the above

3. When hot work is performed in a designated area, a hot work permit is not required.
 - a. True
 - b. False

4. A hot work permit is required anytime hot work is performed in a non-designated area.
 - a. True
 - b. False

5. The person authorized to issue hot work permits is called the _____.
 - a. Permit Issuer
 - b. Competent Person
 - c. Permit Authorizing Individual

6. Unless otherwise specified by the permit, the radius of the combustible-free zone should be _____.
 - a. 10 feet
 - b. 35 feet
 - c. 50 feet

7. Openings or cracks in walls or floors within 35 feet must be covered to prevent the passage of sparks.
 - a. True
 - b. False

8. Which of the following describes a fire watch?
 - a. A trained and authorized person
 - b. Responsible for maintaining a fire-safe condition
 - c. Must watch for fires after work is completed
 - d. All of the above

9. The fire watch is only allowed to watch for fires and does not have the authority to stop the hot work operation.
 - a. True
 - b. False